

FAIRCHILD REPUBLIC A-10C 'WARTHOG' PUNCTUATED STARTUP REFERENCE			
* DENOTES PROCEDURES WHICH MAY NOT BE NECESSARY			
STEP		PROCEDURE	LOCATION
1		SET BAT. SWITCH 'PWR'	FWD. R PANEL
2		SET INV. SWITCH 'STBY'	FWD. R PANEL
3		TEST CAUTION & WARNING SYSTEMS	FWD. L PANEL
4		TEST FUEL INDICATOR	BOT. R DASH
5		SET OXY. SUPPLY SWITCH 'ON'	MID. R PANEL
6		TEST OXY. INDICATOR	MID. R PANEL
7		SET VHF/AM FREQ. MODE DIAL 'TR'	AFT L PANEL
8		SET VHF/FM FREQ. MODE DIAL 'TR'	AFT L PANEL
9		SET UHF FUNC. DIAL 'MAIN'	AFT L PANEL
10		HOLD CANOPY OPER. SWITCH 'CLOSE'	FWD. R PANEL
11		LOCK CANOPY	R CANOPY LIP
12	*	SET INT/EXT LIGHTS AS NECESSARY	AFT R PANEL
13		SET 4X BST. PUMP SWITCH 'ON'	FWD. L PANEL
14		SET 2X (L/R) FUEL FLOW SWITCH 'NORM'	FWD. THROT.
15		SET APU START SWITCH 'START'	FWD. THROT.
~		WAIT APU EGT & RPM STAB.	BOT. R DASH
16		SET APU GEN. SWITCH 'PWR'	FWD. R PANEL
17		SET 2X (L/R) AC GEN SWITCH 'PWR'	FWD. R PANEL
18		SET CDU PWR. SWITCH 'ON'	MID. R PANEL
19		SET EGI PWR. SWITCH 'ON'	MID. R PANEL
20		SET 2X (L/R) MFCD SCREEN BRT/DIM	L/R MFCD
21		SET L THROT 'IDLE'	THROT.
~		WAIT L ENG. STAB.	BOT. R DASH
22		SET R THROT. 'IDLE'	THROT.
~		WAIT R ENG. STAB.	BOT. R DASH
23		TEST CONT. SURF. (STICK, RUD., FLAPS, SB)	N/A
24		SET APU GEN. SWITCH 'OFF'	FWD. R PANEL
25		SET APU START SWITCH 'OFF'	FWD. THROT.
26		UNCAGE/SET SAI LEVEL	L DASH
27		SET CICU PWR. SWITCH 'ON'	BOT. L DASH
28		SET IFFCC PWR. SWITCH 'TEST'	BOT. L DASH
29	*	START IFFCC SELF TEST, PRESS 'ENT'	UFC
30		SET 4X SAS CHANNELS 'ON'	MID. L PANEL
31		HOLD 'T/O TRIM' TO SET T/O TRIM	MID. L PANEL
32		SET EAC 'ARM'	AFT THROT.
33	*	SET L MFCD 'LOAD ALL', PRESS OSB 10	L MFCD
~	*	WAIT DATA LOAD	L MFCD
34		SET R MFCD 'CDU', PRESS OSB 13	R MFCD
~		CHECK IFFCC TESTING COMPLETE	HUD
35	*	EXIT IFFCC TEST, PRESS 'ENT'	UFC
36	*	EXIT IFFCC MENU, SELECT 'EXIT'	UFC
37		SET IFFCC PWR. SWITCH 'ON'	BOT. L DASH
~		WAIT 'INS NAV RDY', 'T=4.0.0.8' MESSAGES	R MFCD
38		SET R MFCD 'NAV', PRESS OSB 9	R MFCD
39	*	SET L MFCD 'TAD', PRESS OSB 15	L MFCD
40	*	SET STEER PT SWITCH 'FLT PLAN'	MID. R PANEL
41	*	SET CMSP MODE SWITCH 'AUTO' OR 'STBY'	FWD. R PANEL
42	*	SET 4X SYSTEM SELECT SWITCH 'ON'	FWD. R PANEL
43	*	SET JTRS PWR. SWITCH 'ON'	BOT. L DASH
44		SET NAV MODE 'EGI'	BOT. DASH
45		SET RDR ALTM SWITCH 'NRM'	AFT THROT.
46		SET ANTI-SKID PWR. SWITCH 'ON'	TOP L DASH
47		SET NWS 'ON'	STICK, PINKY
48		SET EJECTION SEAT ARM LEVER 'ARM'	L SEAT
49		CHECK LASER/GUN/MASTER ARM SWITCHES 'OFF'	BOT. L DASH
50		SET LDG/TAXI LIGHT SWITCH 'TAXI'	TOP L DASH
51	*	SET TGP PWR SWITCH 'ON'	BOT. L DASH
52	*	BLOW KISS TO CREWCHIEF	NOT FAR
THE AIRCRAFT IS READY FOR TAXI			