

<u>Ordinance</u> AGM-65D/G "Maverick"	<u>Guidance</u> IR (PRE+TGP)
BSGT alignment <i>(opt.)</i>	Pre- or In-flight
Set FCR to ON	RH
Set RDR ALT to ON	RH
Set RIGHT HDPT to ON	RH
Set LASER ARM to ARM	LF
Set MASTER ARM to ARM	LF or HOTAS
Set A/G mode	ICP or HOTAS
Select AG65	SMS
Select MSL station	SMS or NWS
MODE to PRE	SMS
Select RIP <i>(as required)</i>	SMS
Select PWR OFF <i>(or auto-cooldown opt.)</i>	SMS
<i>- PWR ON after cooldown (3 min.)</i>	<i>SMS</i>
Select CNI DED page	Dauber RTN
Select the target STPT	ICP
Navigate towards STPT	HUD
Select WPN	SMS
<i>- Camera feed is on</i>	<i>WPN</i>
<i>- MODE is PRE</i>	<i>WPN</i>
Select TRACK POLARITY <i>(for AGM model)</i>	WPN / TMS/I
Set other MFD to TGP page	MFD
Select TGP MFD as SOI	DMS/d
Set Area / Point Track on STPT	TMS/r / TMS/u
Slew to target	Mini-stick
Select Sensor Mode <i>(TV / BHOT / WHOT)</i>	SMS / TMS/I
Select FOV to NARO / WIDE	TPG
Select Zoom Level	TPG / MAN RNG
Select Handoff Mode MAN / AUTO	TPG
Select WPN MFD as SOI <i>(MAN only)</i>	DMS/d
Attempt missile lock <i>(MAN only)</i>	TMS/u
<i>- Confirm missile lock</i>	<i>TPG / WPN / HUD</i>
<i>- Inside effective range</i>	<i>TPG / WPN / HUD</i>
Select WEAPON RELEASE	HOTAS