

| <u>Ordinance</u> | <u>Guidance</u> |
|--|------------------|
| CBU-103/105 WCMD | INS <i>(vis)</i> |
| Set FCR to ON | RH |
| Set MASTER ARM to ARM | LF or HOTAS |
| Set A/G mode | ICP or HOTAS |
| Select CB105 | SMS |
| Select PWR OFF | SMS |
| - <i>System Status is RDY and PWR ON</i> | SMS |
| MODE to VIS | SMS or NWS |
| Select CNTL page | SMS |
| Select BA <i>(2,000 ft recommended)</i> | CNTL |
| Select CNTL | CNTL |
| Select RIP <i>(Single / Pairs Long / Pairs Lat)</i> | SMS |
| Select SEPARATION <i>(ft.)</i> | SMS |
| Slew TD from VV to target <i>(recage with TMS/d)</i> | HUD |
| Designate target | TMS/u |
| Steer to ASL | HUD |
| Hold WPN RELEASE | HUD |