

<u>Ordinance</u>	<u>Guidance</u>
All Rockets <i>(opt. Targeting Pod)</i>	Unguided <i>(CCIP)</i>
Set FCR to ON	RH
Set RDR ALT to ON	RH
Set RIGHT HDPT to ON <i>(opt. TGP)</i>	RH
Set LASER ARM to ARM <i>(opt. TGP)</i>	LF
Set MASTER ARM to ARM	LF or HOTAS
Set A/G mode	ICP or HOTAS
Select rocket	SMS
MODE to CCIP	SMS or NWS
Select SGL / PAIR	SMS
- System Status is RDY	SMS
20°- 30° dive	HOTAS
Set CCIP pipper on target	HUD
Depress laser <i>(opt. TGP)</i>	HOTAS
- In-Range Cue bar over pipper	HUD
Hold WPN RELEASE	HOTAS